

Some lights
always stay off






IMPORTANT

You will not be able to use the new “Glowstone Lighting Plus” app unless you have had a compatible **new controller** installed.

If you are unsure if you have the new controller or want to have one installed you can contact us by phone at 403-453-2224, or email at info@glowstonelighting.com.


#1

The first step is to launch the Glowstone Lighting Plus app and close this “let’s get started” page.




#2

Click “light sets” on the bottom of the page




#3

Sometimes the app defaults back to factory settings. This shows total of 128 lights. Your house may have more lights resulting in a portion of lights being off. To fix this, hit the plus button to add a new light set.




#4

Name the Light Set “House”,
Move the slider bar on range to
the maximum it allows.
Make sure groups of is set to 1
and that distance between
lights is set to 0.




#5

Now delete the light set named Default by clicking here.



#6

Now go back to Live page and select a colour palette to see if all the lights are now working





Thank you!

We hope you Love Coming Home
to your GlowStone Lighting.

Please don't hesitate to reach out with
any questions you may have:

- (403)-710-3381
- Operations@GlowStoneLighting.com